

Showroom

Administrator's Guide

November 2010 www.lexmark.com

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries. All other trademarks are the property of their respective owners.

Edition notice

November 2010

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user's responsibility.

For Lexmark technical support, visit **support.lexmark.com**.

For information on supplies and downloads, visit www.lexmark.com.

If you don't have access to the Internet, you can contact Lexmark by mail:

Lexmark International, Inc. Bldg 004-2/CSC 740 New Circle Road NW Lexington, KY 40550

© 2010 Lexmark International, Inc.

All rights reserved.

UNITED STATES GOVERNMENT RIGHTS

This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

Contents

Edition notice	2
Configuring the application	
Accessing the Embedded Web Server	5
Changing display icons and labels	5
Licensing the application	5
Configuring Showroom	8
Exporting and importing configuration files	g
Using the application from the printer control panel	10
Running a slideshow	10
Troubleshooting	11
Showroom troubleshooting	
Index	12

Configuring the application

This application lets you create and display a customized slide show on the color touch screen of your printer. You can specify how long each slide is displayed, and images can be loaded either from a USB drive or through the printer Embedded Web Server.

Accessing the Embedded Web Server

- 1 Type the device IP address or hostname in the address field of your Web browser.
- 2 Use the navigation menu on the left to access settings and report menus.

Note: If the device IP address or hostname is not readily apparent, you can find it by printing a network setup page.

Printing a network setup page

- 1 From the printer home screen, touch **Menus >Reports >Network Setup Page**. After the network setup page prints, the device will return to the home screen.
- 2 On the printout under TCP/IP, locate the IP Address or Fully Qualified Domain Name.

Changing display icons and labels

You can change the icons and associated text that appear on the printer home screen. If you do not want to use the default icons for an application, you can import new icons to be used for both the pressed and unpressed button states.

Note: For information about compatible image file types and recommended file sizes, see the mouse-over help next to each field.

- **1** From the application configuration settings you can:
 - Specify new Icon Text, to be displayed above the icon on the home screen.
 - Browse to a new icon image file to represent the application on the home screen.
 - **Browse** to a new image file to be displayed while the application icon is being pressed.
- 2 Click Apply to save the settings or Reset to return to the previous settings.

Licensing the application

The application is offered with a license that must be installed in order for the application to function correctly. If individual licenses are used, you must install them locally on each printer. If you plan to use the application with several printers, you may prefer to install the Lexmark License Server and obtain a network license for the appropriate number of devices.

For information about obtaining a license for the application, contact your Lexmark representative.

Obtaining a license file

For local (individual) licensing

- **1** From the Embedded Web Server, do one of the following:
 - Click Settings > Device Solutions > Embedded Solutions.
 - Click Settings or Configuration > Embedded Solutions.
- 2 Click System.
- 3 Record the Host ID (serial number).
 Record only the string that appears after Serial=.
- 4 Contact your Lexmark representative, and provide the Host ID to obtain the license file.

For network licensing

The server Host ID is required to generate the license file for network licensing. To collect the Host ID, contact your system support person and request the MAC address of the computer on which the license server resides. Then contact your Lexmark representative, and provide the Host ID (MAC address) to obtain the license file.

You can also find the Host ID using the Lexmark License Server.

Installing the Lexmark License Server

Note: Lexmark License Server is intended for use with Windows operating systems.

- 1 From the application package, launch the LicenseServer.exe file.
 This executable file is located in <install location>\esf-license-app.
- 2 Click Next.
- 3 Select the installation method you want to use, and then click Next.
 - You have the option to unpack the installation files to a temporary directory from which they will be removed after the installation is complete, or to specify a location where the files will remain after the installation is complete.
- 4 If you do not want the server installed in the default directory, then click **Browse** to select an alternate location.
- **5** Click **Finish** to complete the installation.
- **6** After the Lexmark License Server installation is complete, click **Done**.

Collecting the Host ID

- 1 Click @ or Start > All Programs or Programs > Lexmark > Lexmark License Server > License Administration
- **2** Click the **System Settings** tab.
- **3** Record the Host ID (MAC address).
- 4 Contact your Lexmark representative, and provide the Host ID.

The Host ID is required to generate the license file.

Licensing the printer

Installing an individual license

- 1 From the Embedded Web Server, do one of the following:
 - Click Settings > Device Solutions > Embedded Solutions.
 - Click Settings or Configuration > Embedded Solutions.
- 2 Under Installed Solutions, click the name of the application you are licensing.
- 3 Click License.
- 4 Click Update License.
- **5** Make sure **Local** is selected, and then click **Browse** to locate the license file.
- **6** After locating the appropriate license file, click **Update License**.

Using a network license

Copying the license file to the Lexmark License Server

Note: Before installing a network license, copy the license files to the license server.

- 1 Copy the license file to the following directory on the network license server:C:\Program Files\Lexmark\LicenseServer\Licenses
- **2** On the host computer, open the Control Panel.
- **3** Under Administrative Tools, click **Services**.
- 4 Select License Server.
- **5** Stop and then restart the **License Server** service.

Configuring the network license

- **1** From the Embedded Web Server, do one of the following:
 - Click Settings > Device Solutions > Embedded Solutions.
 - Click Settings or Configuration > Embedded Solutions.
- 2 Click Network License.
- **3** Enter the IP address or hostname and optional port for the network license server where the license is stored. You can enter values for up to three separate servers.
- **4** Specify the **Heartbeat Period** (2–60 minutes), to designate how often the printer will contact the network license server to check for updates and maintain access to an electronic license.
- **5** Specify the **Number of Retries** (1–5), to set the maximum number of times the printer can attempt to obtain a license before quitting.
- 6 Click Apply.

Updating the network license

- 1 From the Embedded Web Server, do one of the following:
 - Click Settings > Device Solutions > Embedded Solutions.
 - Click Settings or Configuration > Embedded Solutions.
- **2** Under Installed Solutions, click the name of the application you are licensing.
- 3 Click License.
- 4 Click Update License.
- 5 Select Network.
- 6 Click Update License.

Configuring Showroom

Creating a slideshow

When selecting images to include in your slideshow, resize or crop source images to the desired size before use. The application does not resize or crop images automatically.

Maximum file sizes and supported file types vary by printer model. For more information, see the mouse-over help in the Embedded Web Server.

Using the Embedded Web Server

- 1 From the Embedded Web Server, do one of the following:
 - Click Settings > Device Solutions > Embedded Solutions > Showroom.
 - Click Settings or Configuration > Embedded Solutions > Showroom.
- **2** Under Showroom Slides, click **Add**.

Note: You can also edit and delete existing slides.

- **3** Enter the Name you want to use for the slide, and then upload the image you want to use.
- **4** If you want to set a different interval for how long this slide displays before changing, check the Override Global Interval box, and then type the number of seconds you want the slide to remain on screen.
- 5 Click Apply.
- **6** Check the Repeat box to re-run the slideshow on a continuous basis.
- 7 Click Apply.

Using a USB drive

- 1 Create a folder on your USB drive containing the images you want to use.
- **2** From the Embedded Web Server, do one of the following:
 - Click Settings > Device Solutions > Embedded Solutions > Showroom.
 - Click Settings or Configuration > Embedded Solutions > Showroom.
- 3 Under USB Drive Settings, select Enable USB Drive.

- 4 For Directory path, type the name of the image file folder you created on your USB drive.
- 5 Under Slide Show Settings, specify the Global interval by typing the number of seconds each slide should be displayed before changing.
- **6** Check the Repeat box to re-run the slideshow on a continuous basis.
- 7 Click Apply.

Exporting and importing configuration files

After configuring an application, you can export your current settings into a file that can then be imported and used to configure that application on one or more additional printers.

Exporting and importing application settings using the Embedded Web Server

Note: Not available on all printer models.

Exporting configuration settings

- **1** From the application configuration settings, click **Export**.
- **2** Follow the browser prompts to save the configuration file. You will have the option to enter a unique file name or use the default name.

Note: If a JVM Out of Memory error occurs, repeat the export until the settings file is saved.

Importing configuration settings

- 1 From the application configuration settings, click Import.
- 2 Browse to the saved configuration file, and then load or preview it.

Note: If a timeout occurs and a blank screen appears, refresh the browser, and then click Apply.

Using the application from the printer control panel

Running a slideshow

Notes:

- The slideshow must first be configured using the Embedded Web Server. For more information, see "Creating a slideshow" on page 8.
- The application may be configured for use with images loaded through the Embedded Web Server and images on a USB drive. If the application is configured for both, images from the USB drive take precedence. The USB drive must be inserted before you touch Showroom.

Running a slideshow from a USB drive

- 1 Insert the drive into the USB port of your printer.
- 2 From the printer home screen, touch **Showroom**. Images will be displayed in alphabetical order.

Note: If the USB drive is removed after Showroom starts, the slideshow will continue. However, the images will not be stored on the printer. If the Slideshow is stopped, the USB drive must be reinserted to access the images again.

Running a slideshow from the Embedded Web Server

To run a slideshow using images loaded through the Embedded Web Server, touch **Showroom** on the printer home screen. Images will be displayed in the order in which they are listed in the Showroom settings.

Troubleshooting

Showroom troubleshooting

Error reading USB drive

Although most USB flash drives should work with your printer, a few may not be compatible. At a minimum, your USB drive should:

- Be USB 2.0-compatible
- Support the Full Speed standard (low-speed devices will not work)
- Have a USB type "A" connector
- Support the FAT file system (NTFS file system not supported)

For a list of tested and approved USB flash drives, visit the Lexmark Web site at www.lexmark.com.

Nothing happens when USB drive is inserted

If nothing happens within a few seconds after you insert your USB drive, then the USB ports may be disabled on the printer. Contact your system support person for more information.

"There are no images to display" error message appears

For images stored on a USB drive

- Remove and reinsert the USB drive to make sure it is properly seated in the printer USB port.
- From the application configuration settings in the Embedded Web Server:
 - Make sure that Enable USB drive is selected.
 - Make sure the directory path to the image files is correct.
 - Make sure that the file size and type are supported. For more information, see the mouse-over help.
 - Click Apply to make sure the configuration has been saved.

For images added through the Embedded Web Server

- From the application configuration settings in the Embedded Web server:
 - Make sure that is a list of image files under Showroom Slides.
 - Make sure that the file size and type are supported. For more information, see the mouse-over help.
 - Click **Apply** to make sure the configuration has been saved.

"Image size exceeds limit" error message appears

If the "Image size exceeds limit" appears, verify that each image file stored on the USB drive or in the Embedded Web Server is no larger than the specified limit.

Index

Α	N
application configuration settings	network settings
exporting 9	finding 5
importing 9	network setup page
	printing 5
D	no images to display error
display icons	troubleshooting 11
changing 5	
	S
E	slide
Embedded Web Server	adding 8
using to access configuration	deleting 8
settings 5	editing 8
exporting	slideshow
application configuration	creating using a USB drive 8
settings 9	creating using the Embedded Web
331	Server 8
н	running 10
home screen icons	Т
changing 5 Host ID	troubleshooting
local (individual) 6	error reading USB drive 11
network 6	image size error 11
network o	no images to display error
1	message 11
· ·	nothing happens when USB drive is
icons	inserted 11
changing 5	
image size error troubleshooting 11	U
importing	USB drive
application configuration	error reading 11
settings 9	nothing happens when
36.611183-3	inserted 11
1	
Lexmark License Server	
installing 6	
license files	
local (individual) 6	
network 6	
licensing	
•	
local 7	
network 7	
individual 7 local 7	